

# How to adjust the dose rate of your Dosing Unit

Accurate dosing of Chrysal products is vital to get the very best results and for longer lasting enjoyment of the flowers. The Chrysal Dosing Unit is supplied pre-set, but if for any reason, this requires altering, adhere to the following instructions

## NO TOOLS ARE REQUIRED




Figure 1

Figure 2

## ADJUSTMENTS SHOULD ONLY BE MADE WHEN THERE IS NO PRESSURE IN THE UNIT

1. Turn off the water supply and allow the pressure to drop by opening the tap
2. Unscrew / slacken the locking ring (Figure 1)
3. Unscrew the adjusting sleeve (Figure 2) so as to bring the top of the sleeve into line with the correct setting
4. Tighten the locking ring (Figure 1)

Chrysal Product	Dose Rate	Setting	
Professional 2 Concentrate	5ml/l	1:200	0.5%
Professional 2 Classic	10ml/l	1:100	1%
Professional 3	10ml/l	1:100	1%
RVB Intensive	1ml/l	1:1000	0.1%



### For more information:

Should you experience any difficulties or feel that your pump is not performing properly, please contact Paul Cooke 07843 339 333 or Chrysal UK.